



STE-5000/6000 Series Cross-Reference

STE-5000 Model	STE-5000 Model Description	STE-6000 Model Replacement	
		(with Screw Clamp Terminals)	(with RJ-45 Connector)
STE-5011-10	ROOM SENSOR; 10K OHM	STE-6011	STE-6010
STE-5012-10	ROOM SENSOR W/DEG.F ADJUSTMENT	N/A, STE-6012*	STE-6014-10
STE-5012-11	ROOM SENSOR W/DEG.C ADJUSTMENT	N/A, STE-6012*	STE-6014-11
STE-5012-14	ROOM SENSOR W/+/- ADJUSTMENT	N/A, STE-6012*	STE-6014 -10/11
STE-5013-10	ROOM SENSOR W/N.O. & L.E.D.	STE-6013	STE-6015
STE-5014-10	ROOM SENSOR W/N.O.;LED;F ADJ.	STE-6020-10	STE-6018-10
STE-5014-11	ROOM SENSOR W/N.O.;LED;C ADJ.	STE-6020-11	STE-6018-11
STE-5014-14	ROOM SENSOR W/N.O.;LED;+/-ADJ.	N/A, STE-6012*	N/A, STE-6016*
STE-5015-10	ROOM SENSOR W/N.O.;3LED;F ADJ.	N/A, STE-6012*	N/A, STE-6016*
STE-5015-11	ROOM SENSOR W/N.O.;3LED;C ADJ.	N/A, STE-6012*	N/A, STE-6016*
STE-5015-14	ROOM SENSOR W/N.O.;3LED;+/-ADJ	STE-6020 -10/11	STE-6018 -10/11
STE-5016-10	ROOM SENSOR;W/INC-DEC SWITCHES	N/A, STE-6012*	N/A, STE-6016*
STE-5017-10	ROOM SENSOR;INC-DEC;N.O.;1LED	N/A, STE-6012*	N/A, STE-6016*
STE-5018-10	ROOM SENSOR;INCR-DECR;1LED	N/A, STE-6012*	N/A, STE-6016*
STE-5021-10	ROOM SENSOR W/N.O. SWITCH	STE-6013	STE-6015
STE-5022-10	ROOM SENSOR W/N.O.;DEG F ADJ.	STE-6019-10	STE-6017-10
STE-5022-11	ROOM SENSOR W/N.O.;DEG C ADJ.	STE-6019-11	STE-6017-11
STE-5022-14	ROOM SENSOR W/N.O.;+/- ADJ.	STE-6020 -10/11	STE-6018 -10/11
STE-5111-10	ROOM SENSOR; 10K OHM	STE-6011	STE-6010
STE-5112-10	ROOM SENSOR W/DEG.F ADJUSTMENT	N/A, STE-6012*	STE-6014-10
STE-5112-11	ROOM SENSOR W/DEG.C ADJUSTMENT	N/A, STE-6012*	STE-6014-11
STE-5112-14	ROOM SENSOR W/+/- ADJUSTMENT	STE-6020 -10/11	STE-6018 -10/11
STE-5113-10	ROOM SENSOR W/N.O. & L.E.D.	STE-6013-10	STE-6015-10
STE-5114-10	ROOM SENSOR W/N.O.;LED;F ADJ.	STE-6020-10	STE-6018-10
STE-5114-11	ROOM SENSOR W/N.O.;LED;C ADJ.	STE-6020-11	STE-6018-11
STE-5114-14	ROOM SENSOR W/N.O.;LED;+/-ADJ.	STE-6020 -10/11	STE-6018 -10/11
STE-5115-10	*SPECIAL ORDER*W/N.O.;3LED;F A	N/A, STE-6012*	N/A, STE-6016*
STE-5115-11	*SPECIAL ORDER*W/N.O.;3LED;C A	N/A, STE-6012*	N/A, STE-6016*
STE-5116-10	ROOM SENSOR;W/INC-DEC SWITCHES	N/A, STE-6012*	N/A, STE-6016*
STE-5117-10	*SPECIAL ORDER*INC-DEC;N.O.;1L	N/A, STE-6012*	N/A, STE-6016*
STE-5118-10	ROOM SENSOR;INCR-DECR;1LED	N/A, STE-6012*	N/A, STE-6016*
STE-5121-10	ROOM SENSOR W/N.O. SWITCH	STE-6013	STE-6015
STE-5122-10	ROOM SENSOR W/N.O.;DEG F ADJ.	STE-6019-10	STE-6017-10
STE-5122-11	ROOM SENSOR W/N.O.;DEG C ADJ.	STE-6019-11	STE-6017-11
STE-5122-14	ROOM SENSOR W/N.O.;+/- ADJ.	N/A, STE-6012*	STE-6014-10
STE-5212-10	ELEC. TEMP. SENSOR; DEG F	N/A, STE-6012*	STE-6014-10
STE-5212-11	ELEC. TEMP. SENSOR; DEG C	N/A, STE-6012*	STE-6014-11
STE-5224-10	ELEC SENSOR W/L.O.;RJ-11;DEG F	N/A, STE-6012*	N/A, STE-6016*
STE-5224-11	ELEC SENSOR W/L.O.;RJ-11;DEG C	N/A, STE-6012*	N/A, STE-6016*
STE-5225-10	ELEC TEMP SENSOR; RJ-11; DEG F	N/A, STE-6012*	N/A, STE-6016*
STE-5225-11	ELEC TEMP SENSOR; RJ-11; DEG C	N/A, STE-6012*	N/A, STE-6016*
STE-5312-10	ELEC. TEMP. SENSOR; DEG F	N/A, STE-6012*	STE-6014-10
STE-5312-11	ELEC. TEMP. SENSOR; DEG C	N/A, STE-6012*	STE-6014-11
STE-5324-10	ELEC SENSOR W/L.O.;RJ-11;DEG F	N/A, STE-6012*	N/A, STE-6016*
STE-5324-11	ELEC SENSOR W/L.O.;RJ-11;DEG C	N/A, STE-6012*	N/A, STE-6016*
STE-5325-10	ELEC TEMP SENSOR; RJ-11; DEG F	N/A, STE-6012*	N/A, STE-6016*
STE-5325-11	ELEC TEMP SENSOR; RJ-11; DEG C	N/A, STE-6012*	N/A, STE-6016*

*Some STE-5000 models have no direct replacement. With only minor changes in the program, however, the STE-6012/6016 can replace any STE-5000 series model, including those with a dial, LED, and switch.